



This information describes the recommended spare parts for the 125 through 1050 lbs. Electric Hoist.

Refer to the Owner's Manual for ED Electric Chain Hoist complete parts list.

Part Name	Parts Per Hoist		Capacity (lbs.)						
			125	220	250	400	350	525	1050
Top Hook Assembly		1	E2D1001125						E3DBX-48S6460
Bottom Hook Comp. Set	S, DS	1	E2D1021125						E3DHX-48S1480
Bottom Hook Comp. Set (Detachable)	DA	1	E2D1002125						
Plug Packing		2	E3S112003						
Chain Guide (Model ED2B)		1	E2D1011125			E2D101350			
Chain Guide (Model ED3A)		1	E3DBX10S9401			E3DBX24S9401			
Cushion Rubber (Model ED2B)		2	E2D046125						
Cushion Rubber (Model ED3A)		2	E3DBX10S9046						
Chain Spring	S, DS	1							E3DBX-48S9590
Carbon Brush		2	E2D502P125				E2D502P350		
Oil Seal		1	E2D236125				E2D236350		
Friction Clutch Assembly (Including Load Sheave)		1	E2D5234-125	E2D5234-220	E2D5234-250	E2D5234-400	E2D5234-350	E2D5234525	
Oil Seal		1	E2D239125				E2D239350		
Converter Assembly	S	1	E2D616125				E2D616350		
	DS	1	E2D616PD125				E2D616PD350		
Silicone Stack Assembly		1	E2D622125				E2D622350		
Electromagnetic Contactor		2	E2D617P125						
Electromagnetic Contactor Complete Set		1					E2D617P350		
Resistor		1	E2D619P125				E2D619P350		

In the column "Parts Per Hoist" a designator is used for parts that apply only to a particular model or option. The designators are:

- S = Single Speed
- DS = Dual Speed
- DA = Dual Speed Cylinder control