



**L5LB Manual Hoist  
Recommended Spare Parts  
3/4 to 9 Ton**

Name	Parts Per Hoist	3/4 Ton	1 Ton	1 1/2 Ton	2 Ton	2 3/4 Ton	3 Ton	6 Ton	9 Ton
Top Hook Assembly	1							L5BU0601001	L5BA0902001
Bottom Hook Assembly	1							L5BU0602001	L5BA0902001
Top Hook Comp. Set	1	L5BU0081001	L5BU0101001	L5BU0151001	L5BU0201001	L5BU0281001	L5BU0301001		
Bottom Hook Comp. Set	1	L5BU0081021	LSBU0101021	LSBU0151021	LSBU0201021	LSBU0281021	LSBU0301021		
Latch Assembly	2	L5BA0081071	L5BA0101071	L5BA0161071	L5BA0251071		L5BA0321071	L5BA0631071	L5BA0901071
Chain Pin	1	L4041008		M3041015	L5BA0259041		L4BH0309041	L4BH0609041	
Slotted Nut	1	M3049005		M3049010	M2049020				
Split Pin	1	9009402		9009411	9009412				
Pinion	1	L5BA0089111		L5BA0169111	L5BA0259111		L5BA0329111		
Gear #2	2	L5BA0089112		L5BA0169112	L5BA0259112		L5BA0329112		
Chain Guide	2	L5BA0089161		L5BA0169161	L5BA0259161		L5BA0329161		
Pawl Spring	2	L5BA0089158		L5BA0169158	L5BA0259158		L5BA0329158		
Snap Ring	2	L4188008						L4188015	
Friction Plate	2	L4151008						L4151015	
Lever Assembly	1	L5BA0086211		L5BA0166211			L5BA0326211		
Brake Spring	1	L4207008						L4207015	
Cam Guide	1	L5BA0089203						L4203015	
Free Chain Spring	1	L4205008						L4205015	
Spring Holder	1	L5BA0089208						L5BA0329208	