


PURPOSE

To provide replacement instruction for ER bottom hook bearing cover (E6S023100).

SCOPE

3 Models: 080S, 100L and 100S.

INSTRUCTION



1. Apply heat to remove the stopper screw from the hook nut.
2. Remove the hook nut and replace the bearing cover.
3. Reinstall the hook nut, and align the stopper screw hole.
4. Reinstall the stopper screw and secure it with Locktite.